

Unable to connect to Bluetooth

1. Please download the appliacation Phomemo from Google Play Store or Apple App Store.



2. Turn on the printer and enable Bluetooth on your phone, please make sure that the distance between the printer and your phone are in 3 meters. iOS





## Android



Note: According to the Google official, for Android 11 and below, GPS permission needs to be enabled to use Bluetooth function; and for Android 12 and above, relative location permission needs to be granted. This

permission does not access your precise location information. You can click on the link below for detailed instructions:

https://developer.android.com/develop/connectivity/bluetooth/bt-permi
ssions

https://developer.android.com/about/versions/12/features/bluetooth-permissions?hl=zh-cn

3. Please open the App Phomemo and connect the printer via Bluetooth. (No need to open the Bluetooth setting on your phone.)

Select your printer model to connect to the app.



If you can't find your printer in the Bluetooth connection page, please turn on the printer, load the paper into the printer and then double-click the power button to print out the QR code, and then click "Scan QR code" at the bottom of the app for Bluetooth connection.



If you still can't find your printer model on the Bluetooth connection page or you can't connect to Bluetooth by scanning the code, and you are using an Android operating system on your phone, please check whether you can find the printer model or serial number (starting with Q) in your phone's Bluetooth list. If you can find the printer model, please follow the steps in the video. Below is the operation video for TO2, which can also be used for other models. You should select the device name according to your printer's model or serial number, and then unpair.

https://www.youtube.com/watch?v=2GtxKZHU9jo&list=PL-guRjwTV0Ybu6f-dFQ T0\_jX1SOWPNcW3&index=2

4. If you still can't connect the printer to the app, please follow the steps below. Make sure all permissions are allowed when installing the app. You can open them in your phone's Settings. Video for enabling permissions on iPhone:

https://www.youtube.com/watch?v=WAsKg3HMdco&list=PL-guRjwTVOYbu6f-dFQ T0\_jX1SOWPNcW3&index=3

Video for enabling permissions on Android phones:

https://www.youtube.com/watch?v=\_1IrKKOvprw&list=PL-guRjwTVOYbu6f-dFQ T0\_jX1SOWPNcW3

Try to turn the printer off and then on again, close the app and then reopen the app again to connect the printer. Try to uninstall and then reinstall the Phomemo App or download the app on another phone, and then try to connect the printer within the app again.

5. If the above steps do not resolve the issue, please provide us with the following information for further testing.

The model name and OS version of your phone.

-	ings		
P	Biometrics & pr	assword	
O	Apps & service		
0	Battery		
0	Storage		
0	Security		
0	Privacy		
8	Digital Balance		
-	HUAWEI Assist	ant	
0	Wallet & Pay		
0	Accessibility fe	atures	
0	Users & accour	ite	
-	HMS Core		
0	System & upda	tes	
	About phone		
← Ab		ny⊇s	
← Ab	<sup>out phone</sup> Harmor	nyQS NIWE	
← Ab	out phone Harmor		
← Ab Device n Model ns	out phone Harmor ame	NOVE	
← Ab Device n Model ns	out phone Harmor	N(W) =	
Ab Device n Model ns Harmony	out phone Harmor eme unter cos version	NOV6 5 10046 500 WLZ-6400	
Ab Device n Model na Model na Hermony Serial nu	out phone Harmor eme unter cos version	NOVA 5 1994 6 (50) WLZ-AND0 (4.0.0	
Ab Device n Model ns Model ns Harmony Serial nu IMEI	out phone Harmor eme unter cos version	NDWA = more 6 (90) WLZ-8400 4.0.0 ADFDU20514010667 B65994045605278	
Ab Device n Model ns Model ns Harmony Serial nu IMEL MEID	out phone Harmor ame unte unter x05 version mber	NDWA = ************************************	
Ab Device n Model na Model na Model na Model na Metal nu IMEI MEID Processo	out phone Harmor ame unte unter x05 version mber	NEWS = NEWS = NEWS = NEZ-AM00 WLZ-AM00 46.0 ADFDU20514050067 ADFDU20514050067 ADFDU20514050067 ADFDU20514050067 ADFDU20514050067 B55954045705847 ADFDU20514050087 B55954045705847 ADFDU20514050087 B55954045705847 ADFDU20514050087 B55954045705847 ADFDU20514050087 B55954045705847 ADFDU20514050087 B55954045705847 ADFDU20514050087 B55954045708 B55954045708 B55954045708 B55954045708 B55954045708 B55954045708 B55954045708 B55954045708 B5595408 B55954045708 B5595408 B55954045708 B55954045708 B55954045708 B55954045708 B55954045708 B55954045708 B55954045708 B55954045708 B55954045708 B55954045708 B55954045708 B55954045708 B5595408 B5595408 B55954045708 B55954045708 B55954045708 B5595408	
← Ab Device n Model ns	out phone Harmor ame ame cos version mber	NEWE + NEWE + NEWE + NEZ - AMOD 46.0 ADFDU20514650667 ADFDU20514650667 B6595469657058647 AD000087FE3131 HUJAWEI (KIM 998	

The version of Phomemo application.



C Durbai Gain Technickeyy Co., Ool

A self-test page of the printer. (After powering on, double-click the power button.)  $% \left( {{\left( {{{\left( {{{\left( {{{\left( {{{\left( {{{{\left( {{{{}}}}} \right)}}} \right.} \right.} \right.} \right)}} \right)}} \right)} \right)} \right)$ 



Abnormal charging /unable to power on (unable to charge, indicator light normal/unable to charge, indicator light off)

1. Make sure that the power socket is charged, and the charging cable and the charging head with an output voltage of 5V-2A can work normally. Use other electrical devices to see if the power socket, the charging cable and charging head can work normally.

2. Reconfirm that the output voltage of the charging head in use is 5V-2A. Fast chargers with output voltage exceeding 5V may damage the printer.



3. If the printer still can't charge, try to replace another 5V-2A charging cable and charging head. After charging for half an hour, check if it can be turned on.

4. While charging, use a thimble or similar tool to poke the reset hole next to the power port. . Restart the printer after charging for half an hour to see if it works properly.

设置格式[企业用户\_223722883]: 正文, 左, 行距: 最小值 0 磅, 图案: 清除(白色)



5. Please follow the instructions to charge the printer properly and do not plug in any adapters or docking stations..



If the above steps do not solve your problem, please send us a video showing the problem encountered when charging your printer.

Printing blanks

1. Make sure you are using thermal paper. You can see if the paper roll is a thermal paper roll on the purchase page of the label. All we sell are thermal paper rolls.

2. Please install the paper correctly. Thermal paper installation video <u>https://www.youtube.com/watch?v=FO-LNTYKS8o&list=PL3\_AhQOD1H\_AinYOnyq6gE\_FOBhqL5-US2&index=3&t=26s</u>

Tattoo paper installation video <u>https://www.youtube.com/watch?v=VeDtIcqJ8SE&list=PL3\_AhQOD1H\_AinYOnyq6gE\_FOBhqL5-US2&index=9</u>

If you are using thermal paper, check the front and back of the thermal paper for misalignment. (The side with the black line should face down when you run your fingernail across the paper.)



3. Double-click the power button to print the QR code.



4. If the print head is jammed, try to press hard to see if it springs back.

Here's the tutorial that may help you. <u>https://www.youtube.com/watch?v=FO-LNTYKS8o&list=PL3 AhQOD1H AinYOnyq</u> <u>6gEFOBhqL5-US2&index=2&t=26s</u> If the problem persists, please provide the following information for further assistance:

Take a video showing the problem so that I can troubleshoot for you.

Provide your printer's SN.



Unclear printing

1. Insufficient battery power can affect printing quality. Please check the battery level of the printer. If it is below 30%, please charge it for 2-3 hours before printing.

Please turn on the printer, load the paper into the printer and then double-click the power button to print out the QR code, (To obtain a more accurate battery level, please print a self-test page without connecting to an external power source.) to check the printer's battery level.



2. Please click print in the app and adjust the print density in the print preview.



3. Clean the print head.

Please clean the print head. Please open the top cover of the printer and locate the print head as shown in the following figure: Wipe the red-framed part, especially the black line, with alcohol cotton to make sure that there is no adhesive or foreign material on the print head.



4. Picture print quality is related to the original picture, if your original picture is fuzzy please replace the picture with a higher resolution and print again, then check the printing effect.

删除[企业用户 223722883]: 5、检测不到热敏纸/纹身纸 ①请正确安装纸张。 热敏纸安装视频 https://www.youtube.com/watch?v=F0-LNTYKS8o&list=P L3 AhQOD1H AinYOnyq6gEFOBhqL5-US2&index=3&t=26s 纹身纸安装视频 https://www.youtube.com/watch?v=VeDtIcqJ8SE&list=P L3\_AhQOD1H\_AinYOnyq6gEF0BhqL5-US2&index=9 ②如果问题依然存在,请按照以下说明操作: 首先,打开打印机,不要放入任何纸张。 其次,长按电源键10-20秒直至打印机指示灯闪烁两次, 然后松开电源键即可完成学习纸张。 最后长按电源键开机,重新装纸即可打印。 https://www.youtube.com/watch?v=f7DIEn7nL6U 如果问题仍然无法解决,请向我们提供以下信息: 请向我们提供一些问题视频,以便我们定位你的问题。 请提供您打印机的 SN 码。



Unable to detect the thermal paper / tattoo paper

1. Please install the paper correctly.

Thermal paper installation video

https://www.youtube.com/watch?v=F0-LNTYKS8o&list=PL3 AhQOD1H AinYOnyq

6gEF0BhqL5-US2&index=3&t=26s

Tattoo paper installation video

https://www.youtube.com/watch?v=VeDtIcqJ8SE&list=PL3 AhQOD1H AinYOnyq 6gEF0BhqL5-US2&index=9

2. If the problem persists, please follow the instructions below: First, open the printer without inserting any paper.

Next, press and hold the power button for 10-20 seconds until the indicator light flashes twice, then release the power button to finish the process. Finally, long press the power button to turn on the printer and then reload the paper to print.

https://www.youtube.com/watch?v=f7DIEn7nL6U

If is the issue still persists, please provide the following information:

Take a video showing the problem so that we can troubleshoot for you.

Please provide the SN of your printer.



Unable to install the driver/driver error

## Windows

1. Please download the corresponding driver according to your computer operating system version and install it according to the prompts.

删除[企业用户\_223722883]: 6、无法安装驱动/驱动异常 Windows: ①请根据您的电脑操作系统版本下载相应的驱动程序,并 按照提示进行安装。 <u>https://phomemo.com/pages/m08f</u> 注意事项: 在与连接电脑前, 请确保打印机己开机。 请确保打印机是与电脑直接连接, 未使用拓展坞。



②如果还是存在异常, 请尝试更换数据线, 并再次尝试 ③请尝试使用其他的 USB 端口进行连接。 若电脑接口有限, 且不得不使用拓展坞的情况下。 请尝 试使用其他的拓展坞再次进行尝试 Mac OS: ①请根据您的操作系统版本下载相应的驱动程序,并按照 提示进行安装。 https://phomemo.com/pages/m08f 视频教程: https://www.youtube.com/watch?v=SL 6F5CPMog 注意事项: 在与连接电脑前, 请确保打印机已开机。 请确保打印机是与电脑直接连接, 未使用拓展坞。 ②如果还是存在异常, 请尝试更换数据线, 并再次尝试 ③请尝试使用其他的 USB 端口进行连接。 ④若电脑接口有限, 且不得不使用拓展坞的情况下。 请 尝试使用其他的拓展坞再次进行尝试。

## https://phomemo.com/pages/m08f

Notes:

Before connecting to the computer, please make sure the printer is turned on.

Please make sure that the printer is directly connected to the computer without using a docking station.



2. If there is still an abnormality, please try to change the data cable and try again.

3. Please try to connect using other USB ports.

If the computer interface is limited and you have to use a docking station. Please try to use other docking stations to try again.

Mac OS

1. Please download the corresponding driver according to your operating system version and install it according to the prompts.

https://phomemo.com/pages/m08f

Notes:

Before connecting to the computer, please make sure the printer is turned on.

Please make sure that the printer is directly connected to the computer without using a docking station.

2. If there is still an abnormality, please try to change the data cable and try again.

3. Please try to connect using other USB ports.

If the computer interface is limited and you have to use a docking station. Please try to use other docking stations to try again.

	/	
Y	删除[企业用户_223722883]: 7、纸张安装 执频纸宏壮加频	
	热敏纸安装视频	
Paper Installation	https://www.youtube.com/watch?v=F0-LNTYKS8o&list=P	
	L3 AhQOD1H AinYOnyq6gEFOBhqL5-US2&index=3&t=26s	
Thermal paper installation video	纹身纸安装视频 …	
https://www.youtube.com/watch?v=F0-LNTYKS8o&list=PL3 AhQOD1H AinYOnyq		
6gEF0BhqL5-US2&index=3&t=26s		
Tattoo paper installation video		
https://www.youtube.com/watch?v=VeDtIcqJ8SE&list=PL3 AhQOD1H AinYOnyq		
6gEF0BhqL5-US2&index=9		
Con opideo operindon o		
•	删除[企业用户_223722883]: 8、检测不到打印机/脱机	
Printer not detected/offline	请先确认您的打印机是否开机。	
First check if the printer is turned on and is connected correctly.		
	Windows: ····	
Windows:		
1. Please download the appropriate driver according to your operating		
system version and follow the instructions to install the driver:		
https://phomemo.com/pages/m08f		
Here's our video tutorial:		
https://www.youtube.com/watch?v=XuCqX8g_kbU		
Make sure the printer is turned on and remains on before connecting to		
make sure the printer is turned on and remains on service connecting to		

Please connect the printer directly to the computer without using a converter.



If the problem persists, please try the following steps.

Try to unplug and re-plug the USB cable.

If your computer has two USB ports, try to switch the other port.

Try to connect using a different USB cable.

We hope these steps will help! But if the problem persists, for a quicker solution, could you please send us videos or pictures showing the problem so that we can provide you a better solution?

Mac:

(1) Please turn on the printer power, and then use a USB cable with data transfer function to connect to the computer, and make sure the port is correct. After the driver installation is completed, please re-plug the data cable.

https://phomemo.com/pages/m08f

② Please try to use another USB cable with data transfer function.

③ The computer has two USB ports, please try to change the port connection.

④ Try to use another USB-A to USB-C adapter or USB-C to USB-C cable to connect the printer and computer.

(5) Select "Add Printer" on your computer to add a printer manually, and restart the printer and computer after adding the printer.

• •	Printers & Scanners			
Search	Default printer	Last Printer Used 🗘		
Privacy & Security	Default paper size	A4 \$		
Desktop & Dock		Printers	E La Carte	1.11
Displays	NO	Printers	_	
Wallpaper	3	Add Printer, Scanner, or Fax	?	in and
Screen Saver	3			
Energy Saver				
Lock Screen				
Login Password				
Users & Groups				
Passwords				
Internet Accounts				
Game Center				
·				
Keyboard				
Mouse				
CDs & DVDs Printers & Scanners				
eninters & scanners	2			
		Videos		
	D 😑 🧰 🛷			
26	) 📰 🥅 🚧	🖆 🚺 🔼	8   📻	>_
26				Ļ
				Ļ
26				Ľ
	Printers & Scanners			
Search			ter Used \$	
	Printers & Scanners			
Search	Printers & Scanners Default printer	Last Print	ter Used \$	
Search	Printers & Scanners Default printer		ter Used \$	
Search Privacy & Security	Printers & Scanners Default printer	Last Print	ter Used ¢ A4 ¢	
Search Privacy & Security Desktop & Dock Displays	Printers & Scanners Default printer	Last Print No Printers	ter Used ¢ A4 ¢	
Search Privacy & Security Desktop & Dock Soloplays Soloplays Socreen Saver	Printers & Scanners Default printer Default paper size	Last Print No Printers Add Printer, Scanner, c	ter Used ¢ A4 ¢	
Search Privacy & Security Desktop & Dock Soloplays Walipaper Screen Saver Energy Saver	Printers & Scanners Default printer	Last Print No Printers Add Printer, Scanner, c Add Printer	ter Used 0 A4 0 or Fax ?	
Search Privacy & Security Desktop & Dock Displays Walipaper Screen Saver Energy Saver Lock Screen	Printers & Scanners Default printer Default paper size	Last Print No Printers Add Printer, Scanner, c Add Printer	ter Used ¢ A4 ¢	
Search Privacy & Security Desktop & Dock Soloplays Soloplays Socreen Saver	Printers & Scanners Default printer Default paper size	Last Print No Printers Add Printer, Scanner, o Add Printer	ter Used 0 A4 0 or Fax ?	
Search Privacy & Security Desktop & Dock Displays Walipaper Screen Saver Energy Saver Lock Screen	Printers & Scanners Default printer Default paper size	Last Print No Printers Add Printer, Scanner, o Add Printer	ter Used 0 A4 0 or Fax ?	
Search Privacy & Security Desktop & Dock Desktop & Dock Displays Wallpaper Screen Saver Lock Screen Login Password Users & Groups	Printers & Scanners Default printer Default paper size	Last Print No Printers Add Printer, Scanner, o Add Printer	ter Used () A4 () or Fax ?	
	Printers & Scanners Default printer Default paper size	Last Print No Printers Add Printer, Scanner, o Add Printer	ter Used 0 A4 0 or Fax ?	
	Printers & Scanners Default printer Default paper size	Last Print No Printers Add Printer, Scanner, o Add Printer	ter Used () A4 () or Fax ?	
	Printers & Scanners Default printer Default paper size	Last Print No Printers Add Printer, Scanner, o Add Printer	ter Used () A4 () or Fax ?	
	Printers & Scanners Default printer Default paper size	Last Print No Printers Add Printer, Scanner, o Add Printer	ter Used () A4 () or Fax ?	
Search Privacy & Security Privacy & Security Desktop & Dock Deskt	Printers & Scanners Default printer Default paper size	Last Print No Printers Add Printer, Scanner, o Add Printer	ter Used () A4 () or Fax ?	
Search Search Desktop & Dock Doblajays Mulipaper Screen Saver Login Password Users & Groups Passwords Internet Accounts Game Center Keyboard Muse	Printers & Scanners Default printer Default paper size	Last Print No Printers Add Printer, Scanner, o Add Printer	ter Used () A4 () or Fax ?	
	Printers & Scanners Default printer Default paper size	Last Print No Printers Add Printer, Scanner, o Add Printer	ter Used () A4 () or Fax ?	
Search Search Desktop & Dock Doblajays Mulipaper Screen Saver Login Password Users & Groups Passwords Internet Accounts Game Center Keyboard Muse	Printers & Scanners Default printer Default paper size	Last Print No Printers Add Printer, Scanner, o Add Printer	ter Used () A4 () or Fax ?	
	Printers & Scanners Default printer Default paper size	Last Print No Printers Add Printer, Scanner, o Add Printer	ter Used () A4 () or Fax ?	
	Printers & Scanners Default printer Default paper size	Last Print No Printers Add Printer, Scanner, o Add Printer	ter Used () A4 () or Fax ?	
Search Privacy & Security Dektop & Dock Displays Swalpaper Screen Saver Cock Screen Login Password Users & Groups Passwords Internet Accounts Game Center Keyboard Mouse Cos & DVDs	Printers & Scanners Default printer Default paper size	Last Print No Printers Add Printer, Scanner, o Add Printer	ter Used () A4 () or Fax ?	

If the above methods do not solve the problem, please provide us with the following information for confirmation:

Check if the machine is connected properly through the Setup and Add Print Queue interface:

	Printers & Scanners		I WE SEA
Search	Default printer	Last Printer Used 😂	Martin Martin
Privacy & Security	Default paper size	A4 🗘	
Desktop & Dock			
Displays	No Printe	rs.	
Wallpaper	3	Add Printer, Scanner, or Fax ?	anni an
Screen Saver	3 🗆		
Energy Saver			Real Property of the
Lock Screen			
Login Password			
Users & Groups			
Passwords Internet Accounts			
Game Center			
Keyboard			
Mouse CDs & DVDs			
Printers & Scanners			
Printers & Scamers	2		
		lideos	
8 🗖 🔁 🖉	D 😑 💳 👦 🛛	<b>étv 🗾 🔼 🎯</b> 🏌	
26			
	Printers & Scanners		
• • •		Last Printer Used 0	
Search	Printers & Scanners		
Q Search	Printers & Scanners Default printer	Last Printer Used ۞ A4 ♀	
	Printers & Scanners Default printer	Last Printer Used 🗘	
Search Privacy & Security Constraints Parkacy & Desktop & Dock	Printers & Scanners Default printer	Last Printer Used ۞ A4 ♀	
Search Privacy & Security Desktop & Dock Displays	Printers & Scanners Default printer	Last Printer Used A4 No Printers	
Search  Privacy & Security  Desktop & Dock  Sipiplays Walipaper Screen Saver	Printers & Scanners Default printer Default paper size	Last Printer Used A4 No Printers Add Printer, Scanner, or Fax ?	
	Printers & Scanners Default printer	Last Printer Used A4 No Printers Add Printer, Scanner, or Fax ? Add Printer	
	Printers & Scanners Default printer Default paper size	Last Printer Used A4 No Printers Add Printer, Scanner, or Fax ?	
	Printers & Scanners Default printer Default paper size	Last Printer Used A4 No Printers Add Printer, Scanner, or Fax ? Add Printer	
	Printers & Scanners Default printer Default paper size	Last Printer Used A4 No Printers Add Printer, Scanner, or Fax ? Add Printer	
Search  Privacy & Security  Desktop & Dock  Displays  Vallpaper  Screen Saver  Energy Saver  Lock Screen  Lock Screen  Login Password  Users & Groups	Printers & Scanners Default printer Default paper size	Last Printer Used () A4 () No Printers Add Printer, Scanner, or Fax (? Add Printer	
Search  Privacy & Security  Desktop & Dock  Sibiplays Walipaper Screen Saver  Lock Screen  Lock Screen  Lock Screen  Users & Groups  Passwords	Printers & Scanners Default printer Default paper size	Last Printer Used © A4 © No Printers Add Printer, Scanner, or Fax ? Add Printer @ @ @	
Search  Privacy & Security  Desktop & Dock  Solsplays Solsplays Screen Saver Energy Saver Lock Screen Lock Screen Login Password Users & Groups Passwords Internet Accounts	Printers & Scanners Default printer Default paper size	Last Printer Used () A4 () No Printers Add Printer, Scanner, or Fax (? Add Printer	
Search  Privacy & Security  Desktop & Dock  Sibiplays Walipaper Screen Saver  Lock Screen  Lock Screen  Lock Screen  Users & Groups  Passwords	Printers & Scanners Default printer Default paper size	Last Printer Used () A4 () No Printers Add Printer, Scanner, or Fax (? Add Printer	
Search  Privacy & Security  Desktop & Dock  Solsplays Solsplays Screen Saver Energy Saver Lock Screen Lock Screen Login Password Users & Groups Passwords Internet Accounts	Printers & Scanners Default printer Default paper size	Last Printer Used () A4 () No Printers Add Printer, Scanner, or Fax (? Add Printer	
Search  Privacy & Security  Desktop & Dock  Valipaper Valipaper Screen Saver Cuck Screen Lock Screen Lock Screen Users & Groups Passwords Isercy Savers Game Center	Printers & Scanners Default printer Default paper size	Last Printer Used () A4 () No Printers Add Printer, Scanner, or Fax (? Add Printer	
Search  Privacy & Security  Privacy & Security  Desktop & Dock  Valipaper Valipaper Screen Saver Energy Saver Lock Screen Lock Screen Login Password Users & Groups Passwords Internet Accounts Game Center Keyboard	Printers & Scanners Default printer Default paper size	Last Printer Used () A4 () No Printers Add Printer, Scanner, or Fax (? Add Printer	
Search  Privacy & Security  Desktop & Dock  Vallapar  Screen Saver  Lock Screen  Lock Screen  Login Password  Users & Groups  Passwords Internet Accounts Game Center  Keyboard  Mouse	Printers & Scanners Default printer Default paper size	Last Printer Used () A4 () No Printers Add Printer, Scanner, or Fax (? Add Printer	
	Printers & Scanners Default printer Default paper size	Last Printer Used () A4 () No Printers Add Printer, Scanner, or Fax (? Add Printer	
	Printers & Scanners Default printer Default paper size	Last Printer Used () A4 () No Printers Add Printer, Scanner, or Fax (? Add Printer	
	Printers & Scanners Default printer Default paper size	Last Printer Used () A4 () No Printers Add Printer, Scanner, or Fax (? Add Printer	
	Printers & Scanners Default printer Default paper size	Last Printer Used () A4 () No Printers Add Printer, Scanner, or Fax (? Add Printer	

Check if the print device exists by typing lpinfo -v through the terminal:



请点击您的打印机型号连接 App

2. If the tattoo paper is installed correctly, double-click the power button to print out the QR code to check if the printer can work normally.



3. Make sure the printer has sufficient battery power. If it falls below 30%, charge it for about 3 hours before starting it again.

4. Use thermal paper instead of tattoo paper for printing and check if the printer works normally.

If the above steps do not solve the problem, please provide us with the printer's serial number (SN) and firmware version.

To find your printer's serial number and firmware version, follow the steps below.

Connect the printer to the "Phomemo" app instead of the Bluetooth on your phone.



Click on your printer model to connect to the app

<	Select a printer
-	<b>T02</b> 00:15:83:29:36:92
	Mr.in 00:15:83:E5:20:39
×.	M02S 9D:2E:4C:BC:54:CB
	U Refresh
_	Can't find a printer?
_	🔒 Scan QR Code

After connecting the printer to the app, click the top right corner of the homepage, and then select the connected printer model from the list to enter the "Manage Devices" page. The serial number and firmware version of the printer are on this page.



Printing black blocks / black lines

1. Try cleaning the print head. Wipe the red framed portion of the printer shown, especially the black line, with alcohol cotton to make sure the print head is free of dirt.



2. Please turn on the printer, load the paper into the printer and then double-click the power button to print out the QR code,

删除[企业用户\_223722883]: 10、打印黑块/黑线 ①请尝试清洁打印头。用酒精棉擦拭图示打印机的红色框 线部分,特别是黑线,以确保打印头上没有污垢。



②请将打印机开机,把纸张装入打印机内然后双击电源键 打印出二维码



如果问题无法解决,请给我拍摄一些问题的视频,以便我 帮助您定位问题。



If the issue persists, please take a video showing the problem so that I can help you localize the problem.