



Brief user guide

Control panel instructions



Remark:


- If you wish to delay the washing machines progress for any reason all you need to do is push the start/pause button again. Pushing the button again will begin the process; if this does not work, restart the machine by pushing the power button, the internal memory will continue its process automatically.
- After an Alarm has sounded due to improper activity, the machine will automatically switch off after 1 hour.
- If the machine is on standby for 10 minutes or longer in operation, the machine will automatically switch off.
- The machine was tested before leaving factory. It's normal if there is some water, please feel easy to use.



Reminder and Error Code

Reminder:

1. Each machine is tested for water intake and drainage during production. Therefore, there may be water residues or traces of water inside the washing tub, which is a normal phenomenon.



2. Please remove the bottom foam before using the new machine! Plastic bracket is only keep the washing machine safe when shipment, the user can remove it or keep it.

Common faults

Error Digital Display Information	Error Reason	How to fix
E1 – Water Inlet Fault	● Incoming water has taken over 20 minutes to reach water level. ● The Inlet Valve is blocked or obstructed. ● The Water supply is cut off or the stopcock is open.	● Check the reason for low water pressure, open and close the cover 1 time to restart operation. ● Remove the blockage from the inlet valve, once done open and close the cover 1 time to restart operation. ● Turn on the water supply or stopcock, once done open and close the cover 1 time to restart operation.
E2 – Drainage Fault	● Water drainage has taken over 5 minutes. ● Drain valve blocked, damaged or faulty. ● Drain pipe is damaged.	● Reposition the drain pipe for a more smooth water drainage, once done open and close the cover 1 time to restart operation. ● Remove the blockage from the drain valve, once done open and close the cover 1 time to restart operation.
E3- Top Cover Fault	● The cover is open during use.	● Close the cover.
E4 – Spin Fault	● Clothes are not level or balanced. ● The machine is standing at an incline.	● Reposition the clothes in the tub so they are balanced and level and close the cover. ● Place the washing machine on a level surface, once done please open and close the cover.
E5 – Water recycle reminder	● The washer is going to drain the water, now you can place the drain pipe in the water tank to collect the gray/waste water.	● Place the drain pipe in the water tank, then open and close the top cover or press the "Start/Pause" key to drain the water.
E6 – Water Level Fault	● Water level sensor fault. ● Water Leakage. ● Harness contact is loose. ● Airway tube is loose.	● Unplug the machine, wait 10 seconds and replug the machine. If issue continues set water level to normal and restart the machine.
E7 – Child Protection	● Machine is Child locked but the cover has been opened.	● Ensure that your child is a safe distance from the machine and close the cover.
Remarks	If unsolved the problem after use above methods, please contact maintenance dept and professional maintenance personnel, customer can not assemble or disassemble.	