FUJIFILM

DIGITAL CAMERA

New Features Guide

Version 5.00

Features added or changed as a result of firmware updates may no longer match the descriptions in the documentation supplied with this product. Visit our website for information on the updates available for different products:

https://fujifilm-x.com/support/download/firmware/cameras/

Contents

X-H2S firmware version 5.00 adds or updates the features listed below. For the latest manuals, visit the following website.

https://fujifilm-dsc.com/en/manual/

No.	Description	X-H2S	See	Ver.
1	Command dial settings can now be configured for each of the P, S, A, and M shooting modes. FRONT COMMAND DIAL 1, FRONT COMMAND DIAL 2, FRONT COMMAND DIAL 3, and REAR COMMAND DIAL can now be configured as command dial settings. In addition, FRONT COMMAND DIAL SWITCH has been added as a function that can be assigned to a function button.	10 298 305	1 13 15	5.00
2	Connection and upload status icons for Frame.io have been added to the electronic viewfinder and LCD mon- itor shooting displays.	14	2 3	4.00
3	SCREEN SET-UP > DISP. CUSTOM SETTING > IMAGE TRANSFER ORDER has been renamed COMMUNICATION STATUS and can now be used to toggle the image transfer order and connected device displays on or off simultaneously.	23	4	3.00
4	FOCUS METER and FOCUS METER + PEAK HIGHLIGHT have been added to the focus check op- tions available during movie recording.	103 204	5 7	2.00
5	Connection and upload status icons for Frame.io have been added to the electronic viewfinder and LCD mon- itor playback displays.	214	8	4.00
6	Items for use when an optional FT-XH file transmitter is attached to the camera have been added to the net-work/USB setting menu.	242	9	2.00
7	ISO sensitivity can now be changed using a command dial.	270	10	5.00

No.	Description	X-H2S	See	Ver.
8	Changes have been made to D BUTTON/DIAL SETTING > ISO BUTTON SETTING > SMARTPHONE TRANSFER ORDER, and SELECT & SMARTPHONE TRANSFER ORDER and))I-Frame.io TRANSFER ORDER options have been added.option has been added.	275	12	4.00
9	The TG-BT1 tripod grip has been added to the optional accessory list.	338	17	3.00
10	Photos and movies can now be uploaded to Frame.io.	343	20	4.00
	Adobe, the Adobe logo, Camera to Cloud, Frame.io, Lightroom and Photoshop are either registered trademarks or trademarks of Adobe in the United States and/or other countries.			

Changes and Additions

Changes and additions are as follows.

X-H2S Owner's Manual: 📖 10 The Command Dials

Ver. 5.00

The rear and front command dials are used for the operations below.

		Front command dial	Rear command dial
	Р	Choose the desired combi- nation of shutter speed and aperture (program shift).	Adjust exposure compensa-
Chardina 1	S	Choose a shutter speed.	tion.
Shooting ¹	A	Adjust aperture. ²]
	М	Adjust aperture. ²	Choose a shutter speed.
	FILTER	Program shift.	Adjust exposure compensa- tion.
Menus		Select menu tabs or page through menus.	Highlight menu items.
Q Menu		Select items in the quick menu.	Adjust settings in the quick menu.
Playback		View other pictures.	Zoom in or out (full-frame playback).Zoom in or out (multi-frame playback).

1 Settings for FRONT COMMAND DIAL 1, FRONT COMMAND DIAL 2, FRONT COMMAND DIAL 3, and REAR COMMAND DIAL can be changed using Z BUT-TON/DIAL SETTING > COMMAND DIAL SETTING.

2 Applies if the lens has no aperture ring or if an aperture ring with an "A" position is in the A position.

The rotation direction for the command dials can be selected using BUTTON/DIAL SETTING > COMMAND DIAL DIRECTION.



- (3) The camera displays icons showing the status of files selected for or currently undergoing upload to Frame.io.
- (9) The camera displays an icon showing the status of the connection to Frame.io.



- The camera displays icons showing the status of files selected for or currently undergoing upload to Frame.io.
- (f) The camera displays an icon showing the status of the connection to Frame.io.

X-H2S Owner's Manual: 🗐 23 Customizing the Standard Display

3 Choose items. Highlight items and press MENU/OK to select or deselect.

- FRAMING GUIDFI INF
- FOCUS FRAME
- AF DISTANCE INDICATOR
- ME DISTANCE INDICATOR
- HISTOGRAM
- I IVE VIEW HIGHLIGHT ALERT
- SHOOTING MODE
- APERTURE/S-SPEED/ISO
- INFORMATION BACKGROUND
 IMAGE SIZE/OUALITY
- Expo. Comp. (Digit)
- Expo. Comp. (Scale)
- FOCUS MODE
- PHOTOMETRY
- SHUTTER TYPE
- FLASH
- CONTINUOUS MODE

- DUAL IS MODE
- TOUCH SCREEN MODE
- WHITE BALANCE
- FILM SIMULATION
- DYNAMIC RANGE
- BOOST MODE
- COOLING FAN SETTING
- FRAMES REMAINING

 - MOVIE MODE & REC TIME
 - COMMUNICATION STATUS
 - MIC | EVEL
 - GUIDANCE MESSAGE
 - BATTERY | EVEL
 - FRAMING OUTLINE

X-H2S Owner's Manual: 📖 103 Checking Focus

Focus Zoom

If **ON** is selected for **AF/MF SETTING** > **FOCUS CHECK**, the camera will automatically zoom in on the selected focus area when the focus ring is rotated. Press the center of the focus stick (focus lever) to exit zoom.

- Use the focus stick (focus lever) to choose another focus area.
 - Zoom can be adjusted by rotating the rear command dial. Zoom cannot, however, be adjusted when **DIGITAL SPLIT IMAGE** or **DIGITAL MICROPRISM** is selected for MF assist.

MF Assist

The focus check options for movies differ from those for still photography.

• **DIGITAL SPLIT IMAGE**: Displays a split image in the center of the frame. Frame the subject in the split-image area and rotate the focus ring until the four parts of the split image are correctly aligned.



- DIGITAL MICROPRISM: A grid pattern that emphasizes blur is displayed when the subject is out of focus, disappearing to be replaced by a sharp image when the subject is in focus.
- FOCUS PEAK HIGHLIGHT: Highlights high-contrast outlines. Rotate the focus ring until the subject is highlighted.
- FOCUS METER: A meter is displayed below the focus point indicating whether focus is in front of or behind the subject. The needle swings left when focus is in front of the subject and right when it is behind the subject. Adjust focus so the needle is pointing straight up.









X-H2S Owner's Manual: 🗐 204 📽 MF ASSIST

Choose how focus is displayed when **MANUAL FOCUS** is selected for **FOCUS MODE**.

Option	Description
FOCUS PEAK HIGHLIGHT	The camera heightens high-contrast outlines. Choose a color and peaking level.
FOCUS METER	A needle indicates whether focus is in front of or behind the subject.
FOCUS METER + PEAK Highlight	Focus is indicated by both a meter and peak highlights.
	Focus is displayed normally (focus peaking and the focus meter are not available).



- (6) The camera displays icons showing the status of files selected for or currently undergoing upload to Frame.io.
- 38 The camera displays an icon showing the status of the connection to Frame.io.

X-H2S Owner's Manual: 📖 242 Network/USB Setting Menus

Adjust camera network and USB settings.

For more information on the network/USB settings menu, visit:

https://fujifilm-dsc.com/en/manual/x-h2s_connection/

The features available when an optional FT-XH file transmitter is attached to the camera are also described.

X-H2S Owner's Manual: 🗐 270 COMMAND DIAL SETTING

The functions of the front command dials and the rear command dial can be configured for each shooting mode.

- 1 Select BUTTON/DIAL SETTING > COMMAND DIAL SET-TING.
- 2 Select a shooting mode.

3 Select the command dial to configure.

Option	

– I	FRONT COMMAND DIAL T
_ 2	FRONT COMMAND DIAL 2
- 3	FRONT COMMAND DIAL 3
-	REAR COMMAND DIAL

Front command dial settings can be saved to FRONT COMMAND DIAL 1, FRONT COMMAND DIAL 2, and FRONT COMMAND DIAL 3. You can switch the settings by pressing the function button to which FRONT COMMAND DIAL SWITCH is assigned.





Ver. 5.00



4 Select the function to assign.

Assignable functions vary depending on the shooting mode.



Shooting Mode	Function	
Р	 PROGRAM SHIFT EXPOSURE COMPENSATION 	• ISO • NONE
S	S.S.EXPOSURE COMPENSATION	• ISO • NONE
А	APERTURE EXPOSURE COMPENSATION	• ISO • NONE
М	• S.S. • APERTURE • EXPOSURE COMPENSATION	• ISO • NONE

• APERTURE applies if the lens has no aperture ring or if an aperture ring with an "A" position is in the A position.

• When the shooting mode is **M**, **EXPOSURE COMPENSATION** only applies if the ISO sensitivity is set to AUTO.

X-H2S Owner's Manual: 📖 275 🕨 ISO BUTTON SETTING

Choose the role performed by the ISO button during playback.

Option	Description	
SMARTPHONE TRANSFER ORDER	Pressing the button marks the current picture for transfer. If the camera is not currently paired with a smartphone, Bluetooth/ SMARTPHONE SETTING options will be displayed.	
⊠ SELECT & SMARTPHONE TRANSFER ORDER	Pressing the button displays a dialog where pictures can be selected for upload to a smartphone with which the camera is paired. If the camera is not currently paired with a smartphone, Bluetooth/SMARTPHONE SETTING options will be dis- played instead.	
EFTP FTP TRANSFER ORDER	Pressing the button marks the current picture for upload to an FTP server.	
FIP FTP PRIORITY	Pressing the button marks the current picture for priority upload to an FTP server. The picture will be moved to the head of the upload queue.	
))I·Frame.io TRANSFER ORDER	Pressing the button marks the current picture for upload to Frame.io.	
	The button can be used for wireless connections.	
IFTP FTP TRANSFER ORDER, IFTP FTP PRIORITY TRANSFER ORDER, and))+ Frame.io TRANSFER ORDER can only be used when an op-		

tional FT-XH file transmitter is connected.

X-H2S Owner's Manual: 🗐 298 Assigning Roles to the Function Buttons

The roles played by the function buttons can be selected using the BUTTON/DIAL SETTING > FUNCTION (Fn) SETTING option in the setup menu.

- ☑ WHEN SETTO M (ON/OFF SWITCH) SHUTTER TYPE
- IMAGE SIZE
- IMAGE QUALITY
- RAW
- FILM SIMULATION
- GRAIN FEFECT
- COLOR CHROME EFFECT
- COLOR CHROME FX BLUE
- DYNAMIC RANGE
- D RANGE PRIORITY
- WHITE BALANCE
- CLARITY
- RECALL CUSTOM 1 SETTING
 IS MODE BOOST
- FOCUS AREA
- FOCUS CHECK
- FOCUS MODE
- AF MODE
- AF-C CUSTOM SETTINGS
- FACE DETECTION ON/OFF
- RIGHT/LEFT EYE SWITCH
- SUBJECT DETECTION ON/OFF
- AF RANGE LIMITER
- FOCUS CHECK LOCK
- SPORTS FINDER MODE
- PRE-SHOT ES A
- SELE-TIMER
- AF BKT SETTING
- FOCUS BKT SETTING
- PHOTOMETRY

- FLICKER REDUCTION
- FLICKERLESS S.S. SETTING
- ISO
- IS MODE
- WIRELESS COMMUNICATION
 - FLASH FUNCTION SETTING
 - TTI -I OCK
 - MODELING FLASH
- MOVIE RECORDING RELEASE
 - HIGH SPEED REC
 - FIX MOVIE CROP MAGNIFICATION

 - 7FBRA SETTING
 - COOLING FAN SETTING
- INTERNAL/EXTERNAL MIC LEVEL ADJUSTMENT
- 4ch AUDIO PLAYBACK
- MOVIE OPTIMIZED CONTROL
 - VIEW MODE SETTING
 - EVF/LCD SWITCH
- PREVIEW DEPTH OF FIELD
- PREVIEW EXP/WB IN MANUAL MODE
- NATURAL LIVE VIEW
 - HISTOGRAM
 - FLECTRONIC LEVEL SWITCH
- LARGE INDICATORS MODE
 - F-Log VIEW ASSIST
 - FRONT COMMAND DIAL SWITCH

Ver. 5.00

- COMMAND DIAL LOCK
- ZOOM/FOCUS CONTROL RING
- CONSTANT SPEED ZOOM (T)
- CONSTANT SPEED ZOOM (W)
- MF CONSTANT SPEED FOCUS (N)
- MF CONSTANT SPEED FOCUS (F)
- AE LOCK ONLY
- AF LOCK ONLY
- AE/AF LOCK

- AF-ON
- AWB LOCK ONLY
- LOCK SETTING
- PERFORMANCE
- AUTO IMAGE TRANSFER ORDER
- Bluetooth ON/OFF
- QUICK MENU
- PLAYBACK
- NONE

To disable the function button, choose **NONE**.

X-H2S Owner's Manual: 📖 305 Assigning Roles to the Lens Function Buttons

The roles played by the lens function buttons can be selected using the **BUTTON/DIAL SETTING > POWER ZOOM LENS** FUNCTION (Fn) SETTING option in the setup menu.

- ☑ WHEN SET TO M (ON/OFF SWITCH) SHUTTER TYPE
- IMAGE SIZE
- IMAGE OUALITY
- RAW
- FILM SIMULATION
- GRAIN FEFECT
- COLOR CHROME EFFECT
- COLOR CHROME FX BLUE
- DYNAMIC RANGE
- D RANGE PRIORITY
- WHITE BALANCE
- CLARITY
- RECALL CUSTOM 1 SETTING

 S MODE BOOST
- FOCUS AREA
- FOCUS CHECK
- FOCUS MODE
- AF MODE
- AF-C CUSTOM SETTINGS
- FACE DETECTION ON/OFF
- RIGHT/LEFT EYE SWITCH
- SUBJECT DETECTION ON/OFF
- AF RANGE LIMITER
- FOCUS CHECK LOCK
- SPORTS FINDER MODE
- PRE-SHOT ES A
- SELE-TIMER
- AF BKT SETTING
- FOCUS BKT SETTING
- PHOTOMETRY

- FLICKER REDUCTION
- FLICKERLESS S.S. SETTING
- ISO
- IS MODE
- WIRELESS COMMUNICATION
 - FLASH FUNCTION SETTING
 - TTI -I OCK
 - MODELING FLASH
- MOVIE RECORDING RELEASE
 - HIGH SPEED REC
 - FIX MOVIE CROP MAGNIFICATION

 - 7FBRA SETTING
 - COOLING FAN SETTING
- INTERNAL/EXTERNAL MIC LEVEL ADJUSTMENT
- 4ch AUDIO PLAYBACK
- MOVIE OPTIMIZED CONTROL
- VIEW MODE SETTING
 - EVF/LCD SWITCH
- PREVIEW DEPTH OF FIELD
- PREVIEW EXP/WB IN MANUAL MODE
- NATURAL LIVE VIEW
- HISTOGRAM
 - FLECTRONIC LEVEL SWITCH
- LARGE INDICATORS MODE
 - F-Log VIEW ASSIST
 - FRONT COMMAND DIAL SWITCH

Ver. 5.00

- COMMAND DIAL LOCK
- ZOOM/FOCUS CONTROL RING
- CONSTANT SPEED ZOOM (T)
- CONSTANT SPEED ZOOM (W)
- ME CONSTANT SPEED FOCUS (N)
- ME CONSTANT SPEED FOCUS (F)
- AE LOCK ONLY
- AF LOCK ONLY
- AE/AF LOCK

- AF-ON
- AWB LOCK ONLY
- LOCK SETTING
- PERFORMANCE
- AUTO IMAGE TRANSFER ORDER
- Bluetooth ON/OFF
- QUICK MENU
 - PLAYBACK
 - NONE
- To disable the function button, choose **NONE**.
 - Selected function lock is not available when CONSTANT SPEED ZOOM (T) or CONSTANT SPEED ZOOM (W) is assigned to a lens function button.

X-H2S Owner's Manual: 🗐 338 Accessories from Fujifilm

The following optional accessories are available from Fujifilm. For the latest information on the accessories available in your region, check with your local Fujifilm representative or visit *https://fujifilm-x.com/support/compatibility/cameras/*.

Rechargeable Li-ion batteries

NP-W235: Additional high-capacity NP-W235 rechargeable batteries can be purchased as required.

Dual battery chargers

BC-W235: The BC-W235 can charge up to two NP-W235 batteries at a time. At +25 °C/+77 °F, the batteries will charge in about 200 minutes. Using a device that supplies power with an outputs of 30 W or above reduces charging times to as little as 150 minutes.

Eye cups

EC-XH W/EC-XT L/EC-XT M/EC-XT S/EC-GFX: Attach viewfinder eyecups to prevent light leaking into the viewfinder window.

Remote releases

RR-100: Use to reduce camera shake or keep the shutter open during a time exposure (e2.5 mm).

Stereo microphones

MIC-ST1: An external microphone for movie recording.

FUJINON lenses

XF-/XC-series lenses: Interchangeable lenses for use exclusively with the FUJIFILM X-mount.

FUJINON MKX-series lenses: Cinema lenses for the FUJIFILM X-mount.

Macro extension tubes

MCEX-11/16: Attach between the camera and the lens to shoot at high reproduction ratios.

Teleconverters

XF1.4X TC WR: Increases the focal length of the compatible lenses by about 1.4×. **XF2X TC WR**: Increases the focal length of the compatible lenses by about 2.0×.

Ver. 3.00

Mount adapters

FUJIFILM M MOUNT ADAPTER: Allows the camera to be used with a wide selection of M-mount lenses.

Body caps

BCP-001: Cover the camera lens mount when no lens is attached.

Shoe-mounted flash units

EF-X500: In addition to manual and TTL flash control, this clip-on flash unit has a Guide Number of 50/164 (ISO 100, m/ft.) and supports FP (high-speed sync), allowing it to be used at shutter speeds that exceed the flash sync speed. Featuring support for the optional EF-BP1 battery pack and Fujifilm optical wireless flash control, it can be used as a commander or remote flash unit for remote wireless flash photography.

EF-BP1: A battery pack for EF-X500 flash units. Takes up to 8 AA batteries.

EF-60: In addition to manual and TTL flash control, this clip-on flash unit has a Guide Number of 60/197 (ISO 100, m/ft.) and supports FP (high-speed sync), allowing it to be used at shutter speeds that exceed the flash sync speed. It can also be used as remote flash under the control of an optional EF-W1 wireless commander.

EF-W1: With support for the NAS^{*} wireless communication standard developed by Nissin Japan, this wireless flash commander can be used with optional EF-60 clip-on flash units and other NAS-compliant units.

* NAS is a registered trademark of Nissin Japan Ltd.

EF-X8: This compact, clip-on flash unit draws power from the camera has a Guide Number of approximately 8/26 (ISO 100, m/ft.) and can cover the angle of view of a 16 mm lens (equivalent to 24 mm in 35 mm format).

EF-42: This clip-on flash unit has a Guide Number of 42/137 (ISO 100, m/ft.) and supports manual and TTL flash control.

EF-X20: This clip-on flash unit has a Guide Number of 20/65 (ISO 100, m/ft.) and supports manual and TTL flash control.

EF-20: This clip-on flash unit has a Guide Number of 20/65 (ISO 100, m/ft.) and supports TTL flash control (manual flash control is not supported).

Vertical battery grips

VG-XH: See "Vertical battery grips".

File transmitters

FT-XH: See "File Transmitters".

Cooling fans

FAN-001: See "Cooling Fans".

Tripod grips

TG-BT1: Record movies, take photographs, or adjust zoom on compatible power zoom lenses while holding this Bluetooth tripod grip.

Grip belts

GB-001: Improves grip. Combine with a hand grip for more secure handling.

Cover kits

CVR-XH: A set of covers for the X-H2S. Contains a sync terminal cap, a hot-shoe cover, and a memory card slot cover, as well as two file transmitter/vertical battery grip connector covers.

instax SHARE printers

SP-1/SP-2/SP-3: Connect via wireless LAN to print pictures on instax film.

Ver. 4.00

X-H2S Owner's Manual: 📖 343 Frame.io Camera to Cloud

Photos and movies can be uploaded directly to the Frame.io platform over a network when the camera is connected to an optional FT-XH file transmitter.

For information on using Frame.io, visit the website below. https://fujifilm-dsc.com/en/manual/x-h2s_connection/

FUJIFILM

FUJIFILM Corporation

7-3, AKASAKA 9-CHOME, MINATO-KU, TOKYO 107-0052, JAPAN https://fujifilm-x.com



