Shipping Label Printer

User Manual



• Read thoroughly before using, keep this for further reference.

MORE CHOICE FOR YOUR GROWING BUSINESS

MUNBYN

MORE CHOICE FOR YOUR GROWING BUSINESS

Contents

1. Product Introduction	2
1.1. What's in the package?	2
1.2. Printer features.	3
2. Set Up The Printer	4
2.1. Quick printer connection.	4
2.2. Use MUNBYN APP to configure network for printer	
on mobile phone.	5
2.3 Connect the printer with the iPhone.	8
2.4 Connect the printer with the Android.	9
2.5 Connect the printer on computer with MacOS System.	11
2.6 Connect the printer on computer with Windows System	12
2.7 Connect the printer on computer with ChromeOS System	14
2.8 Label setup.	15
3. Pro Tips	16
4. FAQ(Frequently-Asked Questions)	16
4.1 How to adjust the density and speed in the settings?	16
4.2 Why is the printed label not clear?	

5 1	partial content missing in the printed labels?	-	17
5. LED Status		_	18

18
18
19
20
21
22
2

1.0. Product Introduction

1.1. What's in the package?



• If contents are missing or damaged, please contact us.

1.2. Printer features

2.0. Set Up The Printer

Watch the short setup video at: munbyn.biz/941APBoxing

2.1. Quick printer connection





1. Power off





2. Connect the power cord and plug in the power supply



3. Power on

WhatsApp: +86 13352950490 • E-mail: Support@munbyn.com

MUNBYN

2.2. Use MUNBYN APP to configure network for printer on mobile phone.

(1) Use the MUNBYN APP to configure the network for the printer on your mobile phone. Search for "Munbyn Print" on the App Store or Google Play to download the app. Alternatively, you can scan the QR code provided to download the app.



Note: The app requires local file access and Bluetooth function to run properly. Please follow the guide to grant the necessary permissions to the app.



(2) After downloading, open the MUNBYN APP, select ITPP941AP, and click "OK" as shown in the picture:



(3) After the software searches for the device, select the Bluetooth device and ensure that the printer and your device are on the same WiFi network. Input the WiFi password and click "Determine," as shown in the figure below:



MUNBYN

(4) After the printer has successfully connected to the network, a pop-up window indicating the successful connection will appear, as shown in the picture:



2.3. Connect the printer with the iPhone

(1) Connect the printer to the iPhone:

Open the file you want to print, tap the "More Options" button in the upper-right corner, and then tap "Print."

Сору	Ф
Markup	\otimes
Print	Ē
Save to Files	
Copy to Printer app	ā

(2) The print preview screen is displayed.

(3) Select the printer that is connected to the same Wi-Fi network.

Cancel	Print Options Pr	rint
Printer	MUNBYN ITPP941AP	>
Presets	Default Settings	>
1 Сору	+	
Paper Siz	e 4 x 6 inches 2	>



(4) After making the selection, adjust the relevant parameters and click on "Print."



switch the paper size to ensure consistency with the labels you are using

24-hour Munbyn after-sales service on working days

WhatsApp: +86 13352950490
 E-mail: Support@munbyn.com

2.4. Connect the printer with the Android

Note: Android system supports only the 4x6-inch size option.

(1) Open the file you want to print, click more options in the upper right corner, and click Print.



(2) The print preview screen is displayed.



(3) Select ITPP941AP, select the corresponding label paper and input the number of printed copies as required.



(4) Clicking the print button.



24-hour Munbyn after-sales service on working days

WhatsApp: +86 13352950490
E-mail: Support@munbyn.com

2.5. Connect the printer on computer with MacOS System.

 Make sure your computer is connected to the same WiFi network/network segment that the printer just connected.
 (You can print a self-check page to see which network the printer is currently connected)

Wi-I	=	
Pref	erred Networks	
(?	ChinaNet-2.4G-lao9	a
(î:	ChinaNet-2.4G-lao9_5G	
?	HYX302	a
	HYX302_5G	a
(;-	SYZ-X	

(2) Add the printer of the corresponding model to the printing device and wait until the system completes adding the printer.

		Add Pri	nter		
		6	ē		
Q Search					
Name			Kind	×	
MUNBYN ITP	P941AP		Bonjour		
-					
-					
-					
					_
Name:	MUNBYN ITPP941	AP 2			
Location:					
Use:	MUNBYN ITPP941	AP			0
?					
\odot					Add
-					
s	etting up 'MUNBYN	ITPP941AP 2			
	_				
S	etting up the device				

(3) Open the file you want to print, click the "Print" button, and then select "ITPP941AP" on the Print preview page.

≪ < 1 of 1 > ≫	Printer: MUNBYN ITPP941AP 2	۲
	Presets: Default Settings	
	Copies: 1	
PRIORITY MAIL 2-DAY MINERN 123 Storet Al, 41 1396 Ubide Tours	Pages: O All From: 1 to: 1	
SHP FO: Amazin Cystaner 1334 AfcArenze Chry Chaste 2015 (101) 223-4546 (101) 223-4546	Paper Size: 4x6 4.00 by 6.00 inches Orientation: ● + Portrait → + Landscape	6
USPS TRACKING #	Scale: 15%	
	Media & Quality 📀	
8803 8203 8055 8203 0358 85	Quality: Draft Normal B	est
? Hide Details	PDF 🕑	ancel Print

2.6. Connect the printer on computer with Windows System.

Note: To enhance your user experience on a Windows system, we recommend clicking the link below to install the printer driver. This will facilitate future adjustments to parameters such as size and print density.

Download link: munbyn.biz/941apwind

(1) Make sure your computer is connected to the same WiFi network/network segment that the printer just connected to (You can print a self-check page to see which network the printer is currently connected to).

24-hour Munbyn after-sales service on working days

WhatsApp: +86 13352950490 · E-mail: Support@munbyn.com

(2) Add the printer to the Windows device and wait for the system to finish adding the printer.(It will take about 2 mins for the Windows system to configure the AP function, please wait patiently.)

Bluetooth & devices > Printers & scanners	
Add a printer or scanner	C Refresh ^
TPP130B-A6F5 Printer	Add device
MUNBYN ITPP941AP Printer	Add device
The printer that I want isn't listed	Show Wi-Fi Direct printers Add manually
Connecting	
Add a printer or scanner	
Ready	

(3) Open the file to be printed, click the Print button, and select ITPP941AP on the Print preview page.

M	UNBYN ITPP941AP V
Cop	ies
1	
Layo	but
0	Portrait
0	Landscape
Pag	es
0	All
\bigcirc	e.g. 1-5, 8, 11-13
Mor	e settings 🗸
Print	using system dialog (Ctrl+Shift+P)

2.7. Connect the printer on computer with ChromeOS System

Please visit the following link and refer to the operation in the video to configure the ITPP941AP on Chromebook:

https://munbyn.biz/ChromeAP

²⁴⁻hour Munbyn after-sales service on working days

2.8. Label setup

Automatic label identification:

- Load no less than 4 consecutive labels into the printer.
- After the paper is stable, press and hold feeder button, until you hear a beep.
- Then, the printer will automatically label identification.
- Pay attention to the front and back sides of the label.



3.0. Pro Tips

- Anytime you change your label, run the automatic label identification.
- Press the feeder button on the printer to skip a blank label.
- To run a self-test, press and hold the feeder button until you hear two short beeps.
- Avoid poor quality labels as they can damage the printer.
- Regularly clean the printer head.
- If the paper is jammed and the red light flashes, run Automatic label identification.

• Insert Munbyn into the same USB port on your computer every time. This will avoid creating duplicate copies of the printer in your operating system.

4.0. FAQ(Frequently-Asked Questions)

4.1. How to maintain the print head?

Here is the video to maintain the print head: munbyn.biz/clean

Here are the steps that maintain the print head:

 Please turn printer off and allow it to cool down (about half a minute)
 Please use alcohol wipes or wipes to clean the print head marked at the following picture.



24-hour Munbyn after-sales service on working days • WhatsApp: +86 13352950490 • E-mail: Support@munbyn.com

3. Please wait 2-5 minutes until the print head dry, then turn the printer on.

4. Please use high-quality thermal label paper (such as Munbyn label paper) as much as possible to prevent the inferior label paper from peeling off and remaining on the print head, which will affect the life of the print head.paper) as much as possible to prevent the inferior label paper from peeling off and remaining on the print head, which will affect the life of the print head.the following picture.

4.2. Why is the printed label not clear?

(1) Try to choose PDF file format for printing instead of PNG, PIG, and other image formats, when the barcode you print out is light (please refer to the picture)

(2) In the print preview interface, switch the print quality option from 'Normal' to 'Best'.

(3) If it is still not clear for the label, you can wipe the print head with alcohol wipes or wet tissues.

For more questions, please visit: <u>https://support.munbyn.com/hc/en-us</u>

4.3. Why is there partial content missing in the printed labels?

This may be due to your document using colors with lower contrast. We recommend switching the print quality option from 'Normal' to 'Best.' Additionally, you can increase the color contrast of your document to resolve this issue.

Printer MUNBYN RW401AP-e3bb >	Media Type	Auto Select >
Presets None >		
ne printer is out of paper (main tray).	PRINT QUALITY	· · · ·
opies 1 - +	Draft No	rmal Best
per Size 4 x 6 inches >		

5.0. LED Status

Light	Description	Troubleshoot
Green	Normal operation	/
Flashing Red (every 1 second)	Label paper is not identified (if not out of paper)	Press and hold the feeder button for one beep to run label identification
Flashing Red (every 1 second)	Out of Paper	Load labels
Flashing Red (every half a second)	Cover is not closed	Check that the cover is completely closed
Flashing Green and Red	Printer head is overheated	Printer will automatically resume once the printerhead has cooled down
Green and Blue	Wi-Fi connected	/
Flashing Green	WPS Mode	Press WPS button on your router or wait 120 second to exit

6.0. Specification

- Press the feeder button once to feed one label through.
- Press and hold the feeder button for one beep to run label identification.
- Press and hold the feeder button for two short beeps to print a test page.

• Press and hold the feeder button for four short beeps to enable WPS mode.

24-hour Munbyn after-sales service on working days

18

WhatsApp: +86 13352950490 · E-mail: Support@munbyn.com

7.0. Specifications

Method	Direct Thermal
Resolution	203 dpi/ 300 dpi
Max Printing Speed	150 mm/s
Paper Width	40-110 mm (1.57-4.3 inches)
Paper Thickness	0.06-0.25 mm
Power Adapter	24V / 2A
Printing Life	TPH 100km
Operating Environment	Temperature: 0 to 50 °C Humidity: 10-90% (non condensing)
Storage Environment	Temperature: -40 to 80 °C Humidity: 5-95% (non condensing)
Connection	USB / WIFI
Weight	1.90 lbs / 0.9kg
Dimensions	D 198mm * W 96mm * H 109mm

8.0. Safety Notices

• The printer head can become very hot after printing labels. Do not touch the printer head.

• Do not bend the power cord excessively or place objects on the cord.

• Do not use the printer if you find any irregularities as these could result in fire or electrocution.

• Keep the printer out of reach of children.

• Use only approved accessories and do not try to disassemble, repair the unit by yourself.

• Keep the printer away from water and other objects that could penetrate the components.

• Please unplug the printer when it is not in use for long periods.

• If you have problems connecting to the printer with the Munbyn Print App, you can try to restart the App or reinstall the App. If your problem is still not resolved, please contact us.

9.0. FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

10.0. Technical Support

If you encounter any issues with the product, please contact us promptly. E-mail: support@munbyn.com WhatsApp: +86 133 5295 0490 Phone: +1 650 206 2250 Skype: munbyn Support time: Monday to Friday 24 hours



MUNBYN provides a 24-month warranty and lifetime free service. If you encounter any issues with the product, please contact the MUNBYN team to promptly receive troubleshooting tips or a replacement. Visit our website at www.munbyn.com for how-to videos and warranty details.

Website: <u>www.munbyn.com</u> (how-to videos, warranty details)

24-hour Munbyn after-sales service on working days s WhatsApp: +86 13352950490 • E-mail: Support@munbyn.com