

USER'S MANUAL Twin-tub Washing Machine Lave-linge à Double Cuves

THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Installation:

Read the instructions carefully before installing the appliance.

The Use of Drain Hose



Preparation Before Use

The proper use of the washing machine is essential for its safe and efficient operation. Please read the instructions carefully before using the machine.



Wash Notice:




Washing Notice

Water Level	Washing Capacity	Washing Time	Washing Type	Washing Time
High	10 kg	1.5-2.0 h	Normal	1.5-2.0 h
Medium	7 kg	1.0-1.5 h	Normal	1.0-1.5 h
Low	4 kg	0.5-1.0 h	Normal	0.5-1.0 h

Read the washing notice carefully before using the machine. The washing time is determined by the amount of laundry and the selected program.


Washing Project



Washing Instructions




PARTS DIAGRAM



Accessories:




NOTES:



SAFEGUARDS:



Trouble Shooting Guide



TABLE

Model	Rated Voltage	Rated Frequency	Rated Power
Washing Machine	110-120V	50/60Hz	1100W

Warning

Children should be supervised to ensure they do not play with the appliance. The appliance is not intended for use by persons lacking adequate knowledge, experience, or technical capabilities. It is not intended for use by persons lacking adequate knowledge, experience, or technical capabilities. It is not intended for use by persons lacking adequate knowledge, experience, or technical capabilities.

SCHEMADES PIÈCES:



Accessories:



REMARQUE:



GARANTIES



INSTALLATION



PRÉPARATION AVANT UTILISATION



AVIS DE LAVAGE



AVIS DE LAVAGE

Water Level	Washing Capacity	Washing Time	Washing Type	Washing Time
High	10 kg	1.5-2.0 h	Normal	1.5-2.0 h
Medium	7 kg	1.0-1.5 h	Normal	1.0-1.5 h
Low	4 kg	0.5-1.0 h	Normal	0.5-1.0 h

PROJET DE LAVAGE



Instructions de Lavage



INSTRUCTIONS DE LAVAGE



ÉLIMINATION APRES LAVAGE




Élimination du linge-linge



DÉPANNAGE



GUIDE DE DÉPANNAGE



TABLEAU

Scale	Washing Capacity	Washing Time	Washing Type	Washing Time
High	10 kg	1.5-2.0 h	Normal	1.5-2.0 h
Medium	7 kg	1.0-1.5 h	Normal	1.0-1.5 h
Low	4 kg	0.5-1.0 h	Normal	0.5-1.0 h

AVERTISSEMENT

Children should be supervised to ensure they do not play with the appliance. The appliance is not intended for use by persons lacking adequate knowledge, experience, or technical capabilities. It is not intended for use by persons lacking adequate knowledge, experience, or technical capabilities. It is not intended for use by persons lacking adequate knowledge, experience, or technical capabilities.

PLEASE give us a chance to make it right and do better!

Contact our friendly customer service department for help first. Repairs for missing or damaged parts will be shipped ASAP!

US Office: Portland OR Office: Ipswich

DE Office: Hamburg FR Office: Saint-Jérôme PL Office: Gdansk

Contact Us!

Do NOT return this item. Contact our friendly customer service department for help first.