

Label Printer



QUICK USER GUIDE

Compatible for AQ00/AQ20/Q00/Q20

01 PACKING LIST


01

Q00 LABEL
PRINTER



02

USB DATA
CABLE *1



03

BUILT IN
BAFFLE *1



04

BUILT IN
RECHARGEABLE
BATTERY *1



SAFETY INSTRUCTIONS




「 SAFETY >
INSTRUCTIONS 」


THIS PRODUCT IS NOT EQUIPPED WITH A STANDARD POWER ADAPTER. PLEASE BE SURE TO USE 3C CERTIFICATION AND MEET THE STANDARD REQUIREMENTS.



**FRONT
SIDE**



**REVERSE
SIDE**



03 EQUIPMENT PARAMETERS



PRINT METHOD

Thermal printing



CONNECTION MODE

Android & iOS & PC



PRINT SPEED

25-56mm/s



POWER ACCESS

DC5V/1.5A



DOT EACH ROW

384 dot/line



PAPER ROLL DIAMETER

50mm



PRINT WIDTH

48mm



PAPER THICKNESS

0.06~0.08mm



PRINT INTERFACE

Bluetooth + USB




BARCODE TYPE

Barcode/QRcode



04 COMPONENT DESCRIPTION

Image



- ① Cover opening button
- ② Left button (Power key/Option)
- ③ Right button (Confirm/Feeding)
- ④ Display Screen
- ⑤ USB interface
- ⑥ Paper storage

Maintenance Tips

-  We recommended you to charge regularly to prevent battery aging if the machine is not used for a long time.
-  It is recommended to clean and maintain the print head regularly.
Use a cotton swab dipped in alcohol to wipe the print head and prolong its service life.

05 PAPER ROLL INSTALLATION

Please do not break the buckle hard, push it down to adjust the size of the paper placement area.

Step 1

Please press on cover opening handle, open the paper storage



Step 2

Please put the paper roll to the left (printing side face to up); slide the baffle to the left



Step 2

Please push the baffle buckle upward to lock the baffle position



Step 4

Please fasten the cover down and press the paper head



Press on right button
feeding test



06 MENU SETTING



Left Button



Right Button

Power Off State

Press the left button long time to turn on the machine, Ring! The display screen lights up to enter the initial state.

Power On State

Press the right button long time to turn off the machine, Ring! The display screen shut down; press the left button to enter the menu mode.

Power On state, (not in the menu mode) press right button to feed the paper.


In Menu Mode

Click on the left button to choose different menu options, the menu options include print darkness; print speed; paper gap, auto feeding and auto power off. No operations for 3 seconds, or press the left button for 3 seconds to exit the menu mode and return to the initial state.

Click on the right button to cycle through the configuration items of the current option

Initial State

Display Screen




Bluetooth、Paper Storage State、
Battery State、Machine ID

Screen indicator


- Bluetooth connected / not connected
- Have paper / No paper
- Battery is charging/ charging is full
- USB data cable connection transmission
- Cover is opened
- Battery is powering
- Menu setting

PRECONDITIONS



STEPS OF CONNECTION


- Click on the connection button from the setting interface
- or click the print icon in the upper right corner of the home page.



Step1


Select the printer you want to connect

Choose the Bluetooth device matching the corresponding printer model




Step2

Bluetooth setting pairing request





Step3



Pairing Bluetooth devices



Step4


the corresponding Bluetooth device "connected"





PUQU

 **PUQULABEL.COM**



APP Download



PUQU Official Account