

Quick Start Guide and FAQ

GETTING STARTED WITH YOUR POLAROID SNAP

Step 1: Charge your camera


Plug the cable into a 1amp charge block and into your camera. Make sure the camera is laid flat on the ground and the cable is not fully extended.



Step 2: Turn on your camera



Step 3: Holding the camera for a selfie



LOAD THE PAPER

Step 1: Take the paper out of the foil. Do not separate the “BLUE COLOR CALIBRATION SHEET”.

Step 2: Load the stack of paper with the “BAR CODE” side face down

A and glossy side face up

B .

STEP 1



STEP 2



PRESS THE POWER BUTTON TO TURN ON THE CAMERA

The LED light will turn white when ready and a chime will sound.



PUSH THE VIEW FINDER DOWN TO TURN THE CAMERA OFF

The LED light will turn white when ready and a chime will sound.



FAQ

Does this printer print pictures from other devices?

The Polaroid Snap only prints the pictures you take from the camera. It does not connect to other devices.

How many sheets can I put in at once?

You can insert up to 10 sheets at a time.

Is there a white border that prints automatically on the film or is that an option you can choose from the camera when taking the picture?

There is a button on the Polaroid Snap that allows you to choose whether or not you want to apply a border to your picture. Once you press the button, it will light up and indicate that your next print will come out with a white border.

Why are my prints coming out black and white/sepia?

These are the other color modes available with the Polaroid Snap. The button on the top left of the camera will allow you to change the color mode.

Can you choose when to print or does it print automatically?

Your Polaroid Snap camera prints automatically.

I have the paper loaded correctly, why is nothing coming out?

Please update your firmware with the instructions here :
<https://www.polaroidsnapcamera.com/snap-firmware/>

Is a MicroSD card required for this camera?

A MicroSD card is not required to use with the Polaroid Snap if you have the Polaroid Premium ZINK® Paper inserted into the camera. If you want to save your photos to your computer you will need to have a MicroSD card in your camera while you take your pictures.

Can I use Zink paper other than Polaroid Premium ZINK™ Paper?

The Polaroid Snap was designed to work only with Polaroid Premium ZINK™ Paper. Other papers may not be compatible with this camera.

What MicroSD cards can be used with the Polaroid Snap?

The Polaroid Snap accepts microSD cards upto 32GB.