


Catalogue

1. How to print the full page	2
2. How to connect the printer to Macbook	12
3. How to connect the printer to Windows computer	24
4. How to print email with Android phone	34
5. How to print email with iPhone	46
6. Which kind of paper can I use to print?	54
7. How can I open the top cover?	55
8. How can I find the replacement papers?	56

How to print the full page

If you use our thermal paper(21cm width) to operate printing, and you want to print the file with no margins, please follow the below instructions step by step:


1. Please open the “HerePrint” APP, and then choose the file which you want to print.



2. Choose the file which you want to print.

	onelogin_log.txt 11月12日, 536 kB, TXT 文档	
	com.kugou.android.2022103... 11月11日, 421 kB, TXT 文档	
	com.kugou.android.support.... 11月11日, 88.40 kB, TXT 文档	
	td.txt 11月10日, 70 B, TXT 文档	
	How it works (1).docx 10月21日, 14.16 kB, DOCX 文档	

3. After you open the file, please click the “Print” icon on the top right corner.



The screenshot shows a document viewer interface. At the top, there is a back arrow on the left, the title 'How it works (1).docx' in the center, and a green circular print icon on the right. A red arrow points to the print icon. Below the header, the document content is displayed on a white background with a light gray border. The content includes a section header 'How it works', a paragraph about automated inventory removal services, a bulleted list of two services, another section header 'Eligible products', a paragraph about eligible products, a bulleted list of two criteria, a section header 'Opting out', a paragraph about default settings, and a numbered list of three steps to opt out.

< How it works (1).docx 

How it works

There are two automated fulfillable inventory removal services that can prevent your inventory from incurring additional storage fees:

- Automated long-term storage removal: The removal of inventory that would be subject to long-term storage fees.
- Automated removal of ASINs with no sale: The removal of units of ASINs that have not sold for six or more consecutive months and that would be subject to applicable storage fees.

Eligible products

The following products are eligible for automated fulfillable inventory removal:

- Units in fulfillment centers for more than 365 days
- Units of ASINs that have not sold in six or more consecutive months and that have been in fulfillment centers for more than 180 days


Opting out

You're opted in to the automated fulfillable inventory removal services by default. To check your status or update your settings, follow these steps:

1. Under Settings, select Fulfillment by Amazon.
2. Scroll down to Automated fulfillable inventory settings and click Edit.
3. To opt out of the services at any time, select Disable and then click Update. You can also opt out of either of the two automated removal services on this page.

4. If you want to print the file which has no margin(full page), please click “Trim whitespace” as the attached picture.

If you want to keep the margin on the printed file, you can skip this step to step 7 directly.



5. Please tick “Trim top and bottom” and “Trim left and right”.

How it works (1).docx

How it works

There are two automated fulfillable inventory removal services that can prevent your inventory from incurring additional storage fees:

- Automated long-term storage removal: The removal of inventory that would be subject to long-term storage fees.
- Automated removal of ASINs with no sale: The removal of units of ASINs that have not sold for six or more consecutive months and that would be subject to applicable storage fees.

Eligible products

The following products are eligible for automated fulfillable inventory removal:

- Units in fulfillment centers for more than 365 days
- Units of ASINs that have not sold in six or more consecutive months and that have been in fulfillment centers for more than 180 days

Opting out

You're opted in to the automated fulfillable inventory removal services by default. To check your status or update your settings, follow these steps:

1. Under Settings, select Fulfillment by Amazon.
2. Scroll down to Automated fulfillable inventory settings and click Edit.
3. To opt out of the services at any time, select Disable and then click Update. You can also opt out of either of the two automated removal services on this page.

Trim whitespace

Trim top and bottom

Trim left and right

6. Click the print icon on the top right corner.




Click the print icon on the top right corner

7. Please click the bottom bar as the attached picture.




Click the bottom bar


8. Adjust “Printing density” to more dark then it can make the printing clearer.




9. Choose the paper width to the loaded paper. If you use our thermal paper(21cm width), please choose “A4” size.



10. Choose printing mode as you need.



11. Click "Print".



Here are two pictures for your reference to check the difference between the print file which clicked "Trim whitespace" and doesn't click "Trim whitespace".

How it works

There are two automated fulfillable inventory removal services that can prevent your inventory from incurring additional storage fees:

- Automated long-term storage removal: The removal of inventory that would be subject to long-term storage fees.
- Automated removal of ASINs with no sale: The removal of units of ASINs that have not sold for six or more consecutive months and that would be subject to applicable storage fees.

Eligible products

The following products are eligible for automated fulfillable inventory removal:

- Units in fulfillment centers for more than 365 days
- Units of ASINs that have not sold in six or more consecutive months and that have been in fulfillment centers for more than 180 days

Opting out

You're opted in to the automated fulfillable inventory removal services by default. To check your status or update your settings, follow these steps:

1. Under **Settings**, select **Fulfillment by Amazon**.
2. Scroll down to **Automated fulfillable inventory settings** and click **Edit**.
3. To opt out of the services at any time, select **Disable** and then click **Update**. You can also opt out of either of the two automated removal services on this page.

Does not click "Trim whitespace"

How it works

There are two automated fulfillable inventory removal services that can prevent your inventory from incurring additional storage fees:

- **Automated long-term storage removal:** The removal of inventory that would be subject to long-term storage fees.
- **Automated removal of ASINs with no sale:** The removal of units of ASINs that have not sold for six or more consecutive months and that would be subject to applicable storage fees.

Eligible products

The following products are eligible for automated fulfillable inventory removal:

- Units in fulfillment centers for more than 365 days
- Units of ASINs that have not sold in six or more consecutive months and that have been in fulfillment centers for more than 180 days

Opting out

You're opted in to the automated fulfillable inventory removal services by default. To check your status or update your settings, follow these steps:

1. Under **Settings**, select **Fulfillment by Amazon**.
2. Scroll down to **Automated fulfillable Inventory settings** and click **Edit**.
3. To opt out of the services at any time, select **Disable** and then click **Update**. You can also opt out of either of the two automated removal services on this page.

Click "Trim whitespace"

Please note: Click "Trim whitespace" the print file will delete the margin and the font will be full of the page.

If you do not click "Trim whitespace", the print file will keep the margin, it will not be full of the page, but the format will be the same as your original print file. Please adjust this function as you need.

How to connect the printer to Macbook

1. Please push the buttons on both sides and open the top cover.



Push the buttons on both sides and open the top cover

2. Load the paper roll to the paper compartment again and pull some extra paper.



Load the paper roll to the paper compartment again and pull some extra paper



Load the paper roll to the paper compartment again and pull some extra paper

3. Plug one side of the USB cable into the printer and the other side into the computer.




Plug one side of the USB cable into the printer and the other side into the computer

4. Hold down the power button for 3 seconds to turn on the printer.




Hold down the power button for 3 seconds to turn on the printer

5. Open the "Browser".




Open the "Browser"


6. Enter “www.hpirt.com/HPRT-MT810” and search it. (You can click this website directly to download the driver on your computer)




7. Click “Mac Driver Download”.




8. Open the driver after downloading it.







9. Click “Allow”.




10. Click “Continue”.




11. Click “Install”.




12. Enter the password for your Apple ID and click “Install Software”.




13. Click “Close”.




14. After the driver has been downloaded, then maybe it will prompt you to remove the driver to trash due to the Macbook has the self-protection mode, but the driver is safe to be used, please click “Keep” to save the driver on your computer.




15. Open the document you want to print.




16. Click File--Print.






Note: Printer name should be "HPRT MT810". If not, please drop down and select.



17. Click "Print".



How to connect the printer to Windows computer

1. Please push the buttons on both sides and open the top cover.



Push the buttons on both sides and open the top cover

2. Load the paper roll to the paper compartment again and pull some extra paper.



Load the paper roll to the paper compartment again and pull some extra paper



Load the paper roll to the paper compartment again and pull some extra paper

3. Plug one side of the USB cable into the printer and the other side into the computer.




Plug one side of the USB cable into the printer and the other side into the computer

4. Hold down the power button for 3 seconds to turn on the printer.




Hold down the power button for 3 seconds to turn on the printer

5. Open the "Browser".




Open the "Browser"


6. Enter “www.hpvt.com/HPRT-MT810” and search it. (You can click this website to download the driver on your computer directly)




7. Click “Win Driver Download”.




8. Click “Open file” after downloading the driver.




9. Click “Yes”.





10. Click “OK”.




11. Click “I accept the agreement”--Next.




12. Click “Next”.




13. Click "Finish".




14. Open the document you want to print.




15. Click the print icon.



Note: Printer name should be “HPRT MT810”. If not, please drop down and select.



16. Click “OK” to print the file.



How to print email with Android phone

1. Hold down the power button for 3 seconds to turn on the printer.



Hold down the power button for 3 seconds to turn on the printer

2. Please scan the QR code on the box or the picture below to download the APP, or you also you can search “HerePrint” APP on the Google play store and then download it.




Download APP

Scan the QR code on the box
to download the APP




Search for "HerePrint"
in APP Store or Google Play to download the APP


3. After downloaded the APP, please turn on the Bluetooth in your phone--open the “HerePrint” APP--click “Connect printer”.




4. Click “Connect”.




5. Open “Gmail” or other email APP.




6. Open the email you want to print.







7. Click "Print".



8. Choose “Save as PDF”.




9. Name this PDF and click “SAVE”.




Name this PDF and click “SAVE”




Name this PDF and click “SAVE”



10. Open the "HerePrint" APP, then click "Documents".




11. Click the button in the upper left corner to access the folder.




Click the button in the upper left corner
to access the folder

12. Click “Downloads”.



Click “Downloads”


13. Click the PDF just saved.




14. Click the print icon on the top right corner.




15. Click the bottom bar.




16. Adjust “Printing density” to more dark it can make the printing clearer.




17. Choose the paper width to the loaded paper. If you use our thermal paper(21cm width), please choose “A4” size.



18. Choose printing mode as you need.



19. Click “Print”.



How to print email with iPhone

1. Hold down the power button for 3 seconds to turn on the printer.



Hold down the power button for 3 seconds to turn on the printer

2. Please scan the QR code on the box or the picture below to download the APP, or you also you can search "HerePrint" APP on the Apple store and then download it.




Download APP

Scan the QR code on the box
to download the APP




Search for "HerePrint"
in APP Store or Google Play to download the APP


3. After downloaded the APP, please turn on the Bluetooth in your phone--open the “HerePrint” APP--click “Connect printer”.




4. Click “Connect”.




5. Open the mail you want to print.




6. Click “Arrow” Mark.




7. Click “Print”.




8. Click the “Share” button in the top right corner.




9. Click “More”.




10. Click “HerePrint”.




11. Click the print icon on the top right corner.




12. Click the bottom bar.




13. Adjust “Printing density” to more dark it can make the printing clearer.




14. Choose the paper width to the loaded paper. If you use our thermal paper(21cm width), please choose “A4” size.



15. Choose printing mode as you need.




16. Click "Print".



Which kind of paper can I use to print?

MT810 portable printer supports 210mm-wide (A4/A5) roll paper and 110mm-wide paper (coming soon!).

You can choose the paper size on the “HerePrint” APP according to the loaded paper.



How can I open the top cover?

Press the buttons in the both side at the same time until pressing to the bottom. You need to press hard with your power.



Push the buttons on both sides and open the top cover



Push the buttons on both sides and open the top cover



Push the buttons on both sides and open the top cover

How can I find the replacement papers?

We have the 210mm-wide (A4/A5) roll paper in stock now.

Paper Size: 210mm x 700mm(8.27in x 21.6in).

Support continuous multi-sheet printing for or long patterns, articles, and files.

Here is a product link for your reference:

https://www.amazon.com/dp/B0B9W9MFB2?ref=myi_title_dp

